

DOUBLE HUNG TILT LATCH LH
30390
DOUBLE HUNG TILT LATCH RH
30391

SCREEN FRAME
30161

SCREEN TENSION SPRINGS
30238

SASH REINFORCEMENT
DEC082-63-1

DIVIDER BAR
30151
DIVIDER BAR CLIPS
30135

DH KEEPER RAIL
8890

PIVOT BAR
30072

GLAZING BEAD
5470
SCREEN MESH
30000

SCREEN LIFT RAIL
30160

SCREEN SPLINE
30002

SCREEN CORNERS
30159

BULB SEAL
8206

FRAME HEAD
8699 - BOX
8689 - FIN

LIFT SASH - TOP
8882

1/4" DH SLOTTED KEEPER - 30094
IMPACT SASH LOCK - 30170

LOCK SASH
8846

DH BOTTOM SASH JAMBS
(NOT PICTURED)
8843

BOTTOM SASH REINFORCEMENT
DEC083-63-1

PULL/LIFT SASH BOTTOM
8883

SILL CLIP
30162

FRAME SILL
8692 - BOX
8672 - FIN

FRAME SILL REINFORCEMENT
DEC096-63-1

